

Fatboy® Headdemock manual



Warning! Read carefully before use!

- The Headdemock can carry a maximum weight of 150 kg. Do not exceed the maximum capacity!
- Only use the Headdemock in combination with the frame.
- Always place the Headdemock on a stable and solid underground.
- Never leave children unattended in the Headdemock.



Instructions for use

- Follow the instructions below to assemble the frame and install the hammock.
- Place the hammock far away from walls, hedges, etc.
- To get into or out of the hammock, take a seating position in the middle of the hammock
- Prevent extreme swinging with the hammock, this may cause accidents.

Instructions for maintenance

- Store the hammock and frame inside after use. In the event your hammock got wet, let it dry thoroughly before storing it in the bag.
- Excess exposure to sunlight, seawater and chlorine can damage your hammock and cause discolorations.
- Check the hooks, straps and rings of your hammock regularly on possible damages or wear and make sure the hammock is assembled correctly according to the instructions below.

Questions or problems?

Please contact your Fatboy® Dealer or Fatboy in the event you have any questions or problems.

Fatboy the original B.V.

De Steenbok 19-21

5215 MG Den Bosch

Netherlands

T: + 31 (0) 73 615 4200 E: service@fatboy.com

W: www.fatboy.com




Visit our website www.fatboy.com for information on warranty on your product.

Fatboy cannot accept any claim on warranty in event of:

Damage or defects caused by use, operation or treatment of the product in ways that are inconsistent with normal personal or domestic use; repairs or attempts to repair undertaken by any party other than Fatboy the original B.V.

Assembly instructions

Frame parts



Instructions

